## **CS-PT1109 Series Pressure Transmitter**

#### **Product Features**

• Ceramic piezo-resistive sensing element

• Measuring range: 0~10/16/25bar Gauge

• Accuracy: 1.5%BFSL

• Output: 4~20mA

• Electrical connection: GX12

• Pressure connection: G1/4

• High accuracy and high cost performance

• Suitable for mass production

### **Applications**

- General pressure measurement
- Air compressor
- Machinery manufacturing
- Measurement and control technology
- Hydraulic and pneumatic technology

## **Product Description**

Designed for general industrial application, CS-PT1109 series pressure transmitters feature compact structure, stable quality and high cost performance.

CS-PT1109series pressure transmitters are widely used in air compressor industry. We can supply you in short term products with different pressure units and pressure connections to meet your specific applications.


#### **Performance Parameters**

Temperature: 25 °C, Power: 24VDC, RH: 45%~75%, Atmospheric pressure: 86KPa∼106KPa

Pressure Range	0~10/16/25bar Gauge		
Output Signal	4~20mA		
Power supply (U+)	10~30VDC		
Output Load	$\leq (U + -10) / 0.023\Omega \text{ (MAX: } 600\Omega \text{)}$		
Over Voltage	30VDC		
Reverse Voltage	-30VDC		
Accuracy at Room Temperature	±1.5% F.S.		
Operating Temperature	-20~85℃		
Storage Temperature	-20~85℃		

Long-term Stability	±0.5%F.S / year			
Settling Time	(10%~90%) ≤10ms			
Overload Pressure	≥ 150% F.S			
<b>Burst Pressure</b>	≥ 200% F.S			
<b>Pressure Connection</b>	G1/4			
<b>Electrical Connection</b>	GX12			
Insulation Resistance	≥ 20MΩ@100VDC			
Insulate Intensity	100VDC@60S, no arc or breakdown			
Vibration Resistance	10g, 5~2000Hz			
Shock Resistance	20g, 11ms half sine			
Ingress Protection	≥ IP54			
Sealings Materialsfor Wetted Part	NBR			
Housing Material	SS304			


# **Structures and Dimensions**



## **Wiring Definition**

GX12	Pin	Definition	Wire Color
GA12		Digital output	
	1	Power Supply+ (U+)	Brown
	2	Current Output (Io)	Blue
	3	Shield (PE)	Yellow

### **Ordering Guide**



## **Notice:**

- a. The pressure transmitter must be used in the medium that is non-corrosive to the seal material and the housing material.
- b. In case the pressure guiding hole of the transmitter is blocked, it is forbidden to use sharp tools to clear it. Instead, one should remove the transmitter from the system, immerse the pressure guiding hole part in the liquid which can dissolve the blockage, and then the blockage will flow out easily.

- c. It's prohibited to open the transmitter by users for calibration or repair.
- d. Please contact us if you're not sure whether the transmitter is suitable for the medium to be measured.
- e. The transmitter should be installed in a location that is not easily bumped or stepped on.
- f. Exceeding of the transmitter overload pressure may cause permanent damage.
- g. Where lightning may occur, customers should consider lightning protection measures.